



**FREE 3 YEAR WARRANTY REGISTRATION
3 ANS DE GARANTIE, INSCRIPTION GRATUITE
REGISTRO DE GARANTÍA DE 3 AÑOS GRATIS
KOSTENLOSE REGISTRIERUNG 3 JAHRE GARANTIE**

三年免费保固

www.AccessoryPower.com/warranty



Please go here to view this document in English:
Pour consulter le document en français, aller sur le lien suivant:
Por favor vaya aquí para ver este documento en Español:
Sie können sich das Dokument hier auf deutsch ansehen:
请到这里查看本文件中英文：

www.AccessoryPower.com/userguides

GOgroove® BlueSYNC™ SLK



FlexARMOR® X Camera Sleeve



 Bluetooth



ReVIVE™
Solar ReStore™
XL+



See more exciting products at:
Voir plus de produits passionnants sur:
Para los productos mas fascinantes visitenos:
Weitere interessante Produkte an:
查看更多精彩的产品:

AccessoryPower.com/promo


Package contents
L'emballage contient
Contenidos del paquete
Packungsinhalt
包装内容



Pal Bot speaker system
 Système de haut-parleurs Pal Bot
 Sistema de altavoces Pal Bot
 Pal Bot Lautsprechersystem
 Pal Bot喇叭

MicroUSB cable
 Câble Micro USB
 Cable de Micro USB
 Micro-USB-Kabel
 microUSB充电线

Product diagram
Schéma du produit
Diagrama de product
Producktabbildung
产品图



- | | | | | |
|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| 1 | 2 | 3 | 6 | 6 |
| AWAKE / SLEEP switch
Bouton marche / arrêt
Botón de PRENDER / Apagar
Aufwecken/Schlafen-Schalter
清醒/睡眠开关 | Volume control
Contrôle du volume
Control de volumen
Lautstärkenregler
音量控制 | 3.5mm retractable audio cable
Câble audio 3.5mm rétractable
Cable de audio retractable de 3.5 mm
3,5mm einziehbares Audiokabel
3.5毫米可伸缩音频线 | | |
| 4 | 5 | 6 | 7 | 8 |
| USB power port
Port d'alimentation USB
Puerto de USB
USB Powerport
USB电源口 | LED eyes
Yeux LED
Ojos LED
LED Augen
LED眼睛 | Moving arms
Bras mobiles
Brazos móviles
Sich bewegende Arme
可调整手臂 | 4-watt speakers
Haut-parleurs 4-Watts
Altavoces de 4-watt
4-Watt Lautsprecher
4瓦喇叭 | Passive bass woofer
Caisson de basse passif
Woofer bajo pasivo
Passiver Basswoofer
无源低音炮 |

Operating instructions

Mode d'emploi

Instrucciones de Operación

Bedienungsanleitung

操作说明

Charging

Charge

Carga

Laden

充电



Connect MicroUSB cable for charging. 2-3 hours = 100 %
Branchez le câble MicroUSB pour le charger. 2-3 heures = 100%
Conecte el cable MicroUSB para cargar. 2-3 horas = 100 %
Zum Laden verbinden Sie das Micro-USB-Kabel. 2-3 Stunden = 100%
连接microUSB充电线进行充电。2-3小时= 100%

Power

Alimentation

Poder

Power

电源



Use the AWAKE/SLEEP switch to turn power on and off.
Utilisez le bouton awake / sleep pour mettre l'appareil sous et hors tension.
Utilice el interruptor del sueño despierto para encender y apagar.
Benutzen Sie den Aufwecken/Schlafen-Schalter um das Gerät an bzw. auszuschalten.
使用清醒/睡眠开关来开启和关闭电源。


Audio

Audio

Audio

Audio

音频



Pull the 3.5mm retractable audio cable and connect it to your audio device.
Tirez le câble audio 3.5mm rétractable et connectez le à votre appareil audio.
Extire el cable de audio retractable de 3.5 mm y únase con su aparato de audio.
Ziehen Sie das 3,5mm Kabel heraus und verbinden Sie es mit dem Audiogerät.
拉出可伸缩的3.5mm音频线连接到您的音频设备。

LED eye power status

LED Eye Color	Battery Status
BLINKING PURPLE	Low power, 30 minutes of run time left ; recharge soon
PURPLE	Charging in progress
BLUE, WHILE CHARGING	Fully charged
BLUE, NOT CHARGING	Power is on ; 1-6 hours of playtime left

Yeux LED pour l'état de charge

Couleur des yeux LED	Etat de la batterie
CLIGNOTEMENT VIOLET	Batterie faible, il reste 30 minutes de fonctionnement ; rechargez rapidement
VIOLET	Chargement en cours
BLEU PENDANT LE CHARGEMENT	Charge complète
BLEU, HORS CHARGEMENT	L'appareil est allumé ; 1-6 heures de fonctionnement

LED estado de la alimentación del ojo

LED Eye Color	Battery Status
BLINKING PURPLE	Low power, 30 minutes of run time left ; recharge soon
PURPLE	Charging in progress
BLUE, WHILE CHARGING	Fully charged
BLUE, NOT CHARGING	Power is on ; 1-6 hours of playtime left

LED Augen Powerstatus

LED Eye Color	Battery Status
BLINKING PURPLE	Low power, 30 minutes of run time left ; recharge soon
PURPLE	Charging in progress
BLUE, WHILE CHARGING	Fully charged
BLUE, NOT CHARGING	Power is on ; 1-6 hours of playtime left

LED eye 电源状态

LED 眼睛颜色	电池状态
闪烁的紫色	低电量 · 剩余30分钟播放时间 · 请尽快充电
紫色	充电中
蓝色 · 充电状态	电池已充满
蓝色 · 未充电状态	电源已打开 · 剩余1-6小时播放时间

Product specifications
Spécifications du produit
Especificaciones del producto
Produktspezifikationen
产品规格

Speakers: 4W RMS (2W x 2); 8W Peak

Audio Input: 3.5mm plug

Audio Cable Length: 24 inches

Power Input: DC 5V

Dimensions: 4.0 x 4.8 x 3.3 inches

Weight: 12.5 ounces

Détails techniques :

Haut-parleurs : 4W RMS (2 x 2W) ; Maximum 8W

Entrée audio : prise jack 3.5mm

Longueur du câble audio : 60.96cm

Puissance d'entrée : 5V DC

Dimensions : 10.16 x 12.19 x 8.38cm

Poids : 354.36gr





www.AccessoryPower.com



Facebook.com/AccessoryPower



Twitter.com/AccessoryPower



ACCESSORY POWER

Android is a trademark of Google, Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Commons 3.0 Attribution License.

© 2013 Accessory Power. All rights reserved. Accessory Power, the Accessory Power logo, GÖgroove, the GÖgroove logo, Pal Bot, and other Accessory Power marks and logos are either registered trademarks or trademarks of Bright Ideas, Inc. in the United States and/or other countries. All other trademarks are the property of their respective owners.

Manufactured in China. Designed in California.

Android est une marque commerciale de Google, Inc. Le robot Android est reproduit ou modifié suite à un travail de création et de partage avec Google et est utilisé conformément aux termes décrits dans la licence Creative Commons Attribution 3.0.

© 2013 Accessory Power. Tous droits réservés. Accessory Power, le logo Accessory Power, GÖgroove, le logo GÖgroove, Pal Bot et les autres marques et logos d'Accessory Power sont soit des marques déposées soit des marques de Bright Ideas, Inc. aux États-Unis et/ou dans d'autres pays. Toutes les autres marques sont la propriété de leurs propriétaires respectifs.

Fabriqué en Chine. Conçu en Californie.

