



MODEL NUMBER: **GRCMACS100BKEW**

FREE 3 YEAR WARRANTY REGISTRATION
3 ANS DE GARANTIE, INSCRIPTION GRATUITE
REGISTRO DE GARANTÍA DE 3 AÑOS GRATIS
KOSTENLOSE REGISTRIERUNG 3 JAHRE GARANTIE
三年免费保固
www.AccessoryPower.com/warranty



For troubleshooting information, please visit the link below:
Pour des informations de dépannage, merci de visiter le lien ci-dessous :
Para obtener información sobre la solución de problemas, visite:
Um Informationen zur Fehlerbehebung zu erhalten, klicken Sie bitte den folgenden Link:

有关疑难解答信息，请点击下面的链接：

www.AccessoryPower.com/FAQ

USA GEAR®

**ACTION
MOUNTS
SERIES™**

A MOUNT FOR EVERY SITUATION
For action and tripod mount cameras

UN SUPPORT POUR TOUTE SITUATION
Pour caméras d'action et supports trépieds



Zip Mount



Chest Strap



Helmet Mount



Head Strap



**Handlebar
Mount**



**Large
Adhesive
Mount**



**Flat
Adhesive
Mount**



Wrist Strap



Suction Mount



www.accessorypower.com/actionmounts

USAGEAR®

CHEST STRAP

4

Package contents L'emballage contient Contenidos del paquete Packungsinhalt 包装内容



Tripod screw adapter
Adaptateur trépied à vis
Tornillo adaptador para trípode
Stativ Schraubadapter
三脚架螺丝连接器




Mount
Support
Soporte
Halterung
支架



Chest strap
Harnais de poitrine
Correa para el Pecho
Brustgurt
束胸带

5

Product diagram
Schéma du produit
Diagrama de product
Produktabbildung
产品图



1
Mount slot
Fente du support
Ranura para el Soporte
Halteungsschlitz
支架卡槽

2
Mount release
Démontage du support
Extracción del Soporte
Halteverschluss
支架解锁

3
Mount screw
Vis du support
Tornillo para Tripode
Halteungsschraube
安装螺栓

4
Shoulder straps
Bretelles
Correa para Hombro
Schultergurte
肩带

5
Chest strap
Harnais de poitrine
Correa para el Pecho
Brustgurte
胸带

6
Chest buckle
Boucle de fixation du
harnais
Hebilla para el Pecho
Brustschnalle
胸扣

7
Adjustment buckles
Boucles de réglage
Ajuste las Hebillas
Verstellchnallen
调整扣

Operating instructions
Mode d'emploi
Instrucciones de Operación
Bedienungsanleitung
操作说明


Connect mount
Fixez le support
Conecte el soporte
Halterung verbinden
连接安装



Insert the mount into the strap until you hear the buckle click
Insérez le support dans la sangle jusqu'à entendre le clic de la boucle
Inserte el soporte en la correa hasta escuchar que la hebilla haga Click
Schieben Sie den Halter in die dafür vorgesehene Öffnung, bis die Schnalle einrastet.
弹簧夾具 弹簧夾具 弹簧夾具 弹簧夾具 弹簧夾具


8

Attach action mount camera
Fixer le support pour caméra
Coloque el soporte para cámara
Befestigen Sie die Action Mount Kamera
安装活动相机支架



Remove the mount screw and insert the camera housing into the mount.
Reinsert the mount screw
Retirez la vis du support et insérez le boîtier de la caméra dans le support. Remettez la vis du support
Remueva el tornillo del soporte e inserte la carcasa de la camara en el soporte.
Reinserte el tornillo para soporte
Lösen Sie die Schraube und befestigen Sie das Kameragehäuse in der Halterung.
Schrauben Sie die Halterungsschraube wieder fest.
取出支架螺栓插入相机座到支架·再插入支架螺栓。

9



For a secure thread connection, press the nut outwards with the screw and then tighten



Pour une fixation sécurisée, positionnez l'écrou sur la vis, vissez et bien serrez

Para una conexión segura, presione la tuerca hacia afuera con el tornillo y luego ajuste

Für einen sicheren Gewindeanschluss, drücken Sie die Mutter mit der Schraube nach außen und ziehen Sie sie dann fest


为了连接安全，请按住向外的螺帽然后拧紧螺栓。

10



11

Attach tripod mount camera
Fixer le support trépied de la caméra
Coloque el soporte para trípode
Befestigen Sie die Tripod Mount Kamera an
安装相机三角架



Remove the mount screw and insert the tripod screw adapter into the mount. Reinsert the mount screw. Insert the tripod screw into your camera's tripod socket and tighten

Retirez la vis du support et insérez l'adaptateur pour la vis de trépied dans le support. Remettez la vis du support. Insérez l'adaptateur trépied à vis dans la prise de trépied de l'appareil photo et serrez.

Remueva el tornillo del soporte e inserte el tornillo adaptador para trípode en el soporte. Reinserte el tornillo del soporte. Inserte el tornillo para trípode en el agujero de su cámara y ajuste.

Lösen Sie die Schraube und befestigen Sie das Kameragehäuse in der Halterung. Schrauben Sie die Halterungsschraube wieder fest. Drehen Sie dann die Stativschraube in das Stativgewinde Ihrer Kamera.

取出支架螺栓把三角架螺丝连接器插入支架，再插入支架螺栓。把三角架螺丝插入相机三角架螺丝孔并拧紧。

12

Adjust
Régler
Ajuste
Einstellen
调校



Place the shoulder straps and wrap the chest strap around yourself. Insert the chest buckle

Placer les bretelles et enveloppez la sangle ventrale autour de vous. Insérez la boucle ventrale

Coloque las correas para hombro y envuelva la correa para el pecho alrededor de usted. Inserte la hebilla para el pecho

Legen Sie die Schulter- und Brustgurte an und befestigen Sie die Brustschnalle.

穿戴肩带和胸带在你身上，插上胸扣。

13



Use the Adjustment buckles for sizing

Utilisez les boucles de réglage pour obtenir l'ajustement désiré

Utilice las hebillas para ajustar al tamaño deseado

Passen Sie mit Hilfe der Schnallen den Sitz an.

利用调整扣调整大小。

14



Position the camera to your desired angle and make sure all screws are secure

Placez la caméra avec l'angle souhaité et assurez-vous que toutes les vis et boucles soient sécurisées

Coloque la cámara en el ángulo deseado y controle que todos los tornillos esten ajustados

Richten Sie die Kamera aus und vergewissern Sie sich, dass alle Schrauben angezogen sind

放置相机到您想要的角度并确保所有螺丝安全紧固。

15

Product specifications
Spécifications du produit
Especificaciones del producto
Produktspezifikationen
产品规格

Technical specifications:

Chest circumference: 25 – 72 inches

Shoulder to chest height: 11 – 18 inches

Weight: 5.76 ounces

Détails techniques :

Tour de poitrine : 63,5 - 182,88 cm

Hauteur épaules-poitrine : 27,94 - 45,72 cm

Poids : 163,29 g

Trademark information Informations sur la marque déposée

GoPro

GoPro, HERO, the GOPRO logo, and the GoPro Be A Hero logo are trademarks or registered trademarks of GoPro, Inc.
Works with GoPro's Hero camera

Toshiba Camileo X-Sports

Camileo is a registered trademark of Toshiba America Information Systems, Inc.
Toshiba and the Toshiba logo are registered trademarks of Toshiba Corporation.

Coleman Xtreme Action Camera

Coleman and the Coleman logo is a trademark or registered trademark of The Coleman Company, Inc.

Drift HD Ghost

Drift, the HD Ghost logo, and the Drift Logo are trademarks or registered trademarks of Drift Innovation

iON AIR PRO

The ion logo is a registered trademark of World Wide Licenses Limited.
AIR PRO and its respective logo is a trademark or registered trademark of World Wide Licenses Limited in the United States and other countries

JVC ADIXXION

ADIXXION is a trademark or registered trademark of JVC Kenwood Corporation of Japan
JVC is a registered trademark of JVC Kenwood Corporation of Japan

KODAK PIXPRO

Kodak and the Kodak logo are registered trademarks of Eastman Kodak Company

Midland XTC

Midland and the Midland logo are registered trademarks of Midland Radio Corporation

Polaroid XS

Polaroid, Polaroid Classic Border Logo, Polaroid Color Spectrum are registered trademarks of PLR IP Holdings, LLC.

SONY HDR

Sony and HDR are trademarks or registered trademarks of Sony Corporation

Swann Freestyle

Swann and the Swann logo are registered trademarks of Swann Communications Ltd.

Veho Muvi

Veho and Muvi are trademarks or registered trademarks of Veho UK Ltd.

Pentax

Pentax is a registered trademark of HOYA Corporation

Panasonic

Panasonic is the registered trademark of Panasonic Corporation

Canon

Canon is the registered trademark or trademark of Canon Inc. and/or other members on the Canon Group

Fujifilm

Fujifilm is a registered trademark or trademark of Fujifilm Corporation

Nikon

Nikon is a registered trademark or trademark of Nikon Corporation

Olympus

Olympus is a registered trademark or trademark of Olympus Corporation

Samsung

Samsung is a trademark of Samsung Electronics Co.



[YouTube.com/AccessoryPower](https://www.youtube.com/AccessoryPower)



[Facebook.com/AccessoryPower](https://www.facebook.com/AccessoryPower)



[Twitter.com/AccessoryPower](https://www.twitter.com/AccessoryPower)



ACCESSORY POWER®

© 2014 AP Global, Inc. All rights reserved. Accessory Power, the Accessory Power logo, USA GEAR, USA GEAR Action Mount Series, the USA GEAR logo, and other Accessory Power marks and logos are either registered trademarks or trademarks of AP Global, Inc. in the United States and/or other countries. All other trademarks are the property of their respective owners.

Manufactured in China. Designed in California.

© 2014 AP Global, Inc. Tous droits réservés. Accessory Power, le logo Accessory Power, USA GEAR, USA GEAR Action Mount Series, le logo USA GEAR, et les autres marques et logos d'Accessory Power sont soit des marques déposées soit des marques de AP Global, Inc. aux États-Unis et/ou dans d'autres pays. Toutes les autres marques sont la propriété de leurs propriétaires respectifs.

Fabriqué en Chine. Conçu en Californie.



**WARNING! THIS PRODUCT IS NOT LIFE SAVING EQUIPMENT.
AVERTISSEMENT! CE PRODUIT N'EST PAS UN EQUIPEMENT DE SAUVETAGE.**

